

jSAX 2.0



Congratulations!

We hope you will enjoy your new jSax as much as we've enjoyed developing it. The jSax can help you learn some essential skills for playing the traditional saxophone as well as give you a taste of the fun that goes with playing the sax.

Music

Your jSax follows some traditional fingering patterns for the saxophone and is tuned in the key of C. This means you can play along with any music for instruments tuned in C which includes recorder, Toot, Dood, Clarinéo, flute, guitar or piano. You can go to www.nuvo-windstars.com to find lots of free downloads of fun music and backing tracks

The note range of the jSax is from middle C to G one octave higher (see fingering chart). To get the second octave simply rock your thumb to open up the small vent hole on the left hand thumb rest. This is a similar action to pressing the thumb key on a traditional sax.


Reeds

Your jSax 2.0 uses Nuvo synthetic reeds which are included. These are available in 3 strengths. Try 1 ½ to start with then you can progress to 2. You can also use any soprano sax reed or Eb clarinet reed.

Note: Nuvo reeds are much more durable than cane reeds but you still need to take good care of them. If the tip is bent or damaged even slightly, it will not play and you will need to replace it.


Setting up your ¡SAX

When the reed needs to be changed, simply open the ligature as shown in the picture and carefully slide the reed up and away from the mouthpiece. Remember not to touch the tip of the reed. There is a ridge on the back of the reed which fits into a slot on the mouthpiece. Slide the reed into the slot as far as possible and then release the ligature as shown. This provides correct alignment every time. The tip of the reed should now be aligned with the tip of the mouthpiece.






Now assemble the neck, mouthpiece and bell as indicated in the following diagram. Take care to make sure the 4 o-rings on the neck do not get displaced during assembly.



Training Wheels!

If you are finding it difficult to cover the tone holes or reach the pinky key, you may like to try out the Key Plugs. Like training wheels on a bicycle, these will help you to get started and when you feel ready you can take them off which will open up more notes.



Straighten your jSAX

The standard jSax comes with the familiar curved form of the saxophone. This is very suitable for children from 4 to 14 years but if you are an adult you may find it more comfortable to straighten your jSax. Ask your local dealer for the 'Straighten Your jSax Kit' which includes a straight neck and bell. These will both fit in your case in place of the curved ones.



Playing your ¡SAX

You can download the free 'Play It Today' jSax book from the Nuvo website - www.nuvo-instrumental.com. The book contains some basic tips and tunes to play along with. If you are having trouble with your first notes, you can also refer to the YouTube videos or ask a local sax teacher for a lesson.

Teachers

If you're a saxophone teacher you will find the jSax useful for introducing some basic sax concepts to younger students who wouldn't normally be ready to start. If you're a general music teacher you might like to consider starting a Nuvo WindStars band using jSax, Doods, Toots, Clarinéos and Flutes. All are pitched in C and can use the free music available on the WindStars website -

Community

We would love to hear from you about your experiences playing your jSax. Share with the Nuvo community online! Please post your You Tube videos and if you have some tunes you'd like to share at www.nuvo-windstars.com, please contact me directly.

Cleaning and Care

Your jSax is super-durable just like all Nuvo instruments and it loves to go camping, hiking, climbing and even swimming! Try to avoid sand but if it does get a little sandy you can give it a good bath in warm soapy water. Oh, you can even play it in the shower!

KEEP IT OUT! (KIO)

Finally, we encourage you to "Keep it Out!". Your jSax will not easily get broken so it doesn't need to live in the case. Keeping it out gives you the chance to practice whenever the mood grabs you.

Let us know how you get along with your iSax.



max@nuvo-instrumental.com





DUE TO SMALL PARTS, NOT SUITABLE FOR CHILDREN UNDER 36 MONTHS.

© 2018 NUVO Instrumental (Asia) Ltd. All rights reserved. Manufactured in China by NUVO Instrumental (Asia) Ltd. Hong Kong

PATENT PENDING

